
Shaker | Print Guidelines




The following print guide has been prepared for your graphic designer, however should you not have a graphic designer, Flashbay is happy to lay out your artwork and/or text which you can email to your Flashbay account manager. Having submitted your artwork to Flashbay, you will receive a virtual PDF for your review. We can make modifications thereafter as requested.

Screen Printing







Printing specification:

► CMYK colour mode ► Vector files preferably ► 300dpi for rasters